



PIPE BOX DETAIL
 NO SCALE

GENERAL NOTES

1. PIPE BOX NEEDS TO BE SOLDERED TO THE TOP OF COPPER COVER. SEE CURB DETAIL, LINES RUN INSIDE OF CURB. BOX TO BE MADE OF 16OZ COPPER.
2. SOLDER ALL CORNERS AND EDGES.
3. FASTEN TOP TO BOTTOM WITH STAINLESS STEEL SCREWS.
4. SLOPE OF PIPES IS TO BE AWAY FROM BOX.
5. TOP OF BOX TO BE 8" ABOVE ROOF MINIMUM.

IRMA_PIPE_BOX_DETAIL.dwg

DATE	9/15/2016
DRAWN	
REVISION	00/00/00 BCHARLAND
DETAIL NO.	XXXXXX-XX
SHEET	1 OF ONE